

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922) 49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
 Иваново (4932)77-34-06
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Саранск (8342)22-96-24
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сыктывкар (8212)25-95-17
 Сургут (3462)77-98-35
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольяти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Улан-Удэ (3012)59-97-51
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://goldeneagle.nt-rt.ru> || geo@nt-rt.ru

Лапки специальные для швейных машин

HEMMER FOOT for SINGLE NEEDLE LOCKSTITCH MACHINES

Thin material



NO.1	1/16"(1.6mm)
NO.1 1/2	5/64"(2.0mm)
NO.2	3/32"(2.4mm)
NO.2 1/2	1/8"(3.2mm)
NO.3	5/32"(4.0mm)
NO.4	3/16"(4.8mm)
NO.5	7/32"(5.6mm)
NO.6	1/4"(6.4mm)
NO.7 1/2	5/16"(8.0mm)

Thick material



NO.02	1/8"(3.2mm)
NO.04	3/16"(4.8mm)
NO.06	1/4"(6.4mm)
NO.07	5/16"(8.0mm)
NO.09	3/8"(9.5mm)
NO.095	7/16"(11.1mm)

PRESSER FOOT for OVERLOCK & INTERLOCK SEWING MACHINES



P253E-4(WITH HEAD)
for SIRUBA
[747D-512M1-24](#)



P502-A
for SIRUBA
[757-516M2-55](#)



S19280-001
for BROTHER
[EF4-N21-22-4](#)



S19313-201
for BROTHER
[EF4-N31-63-3](#)



S19317-001
for BROTHER
[EF4-N31-65-5](#)



S19334-001
for BROTHER
[EF4-N31-92-5](#)



208504
for PEGASUS
[L32 / M732-38.39](#)



201230C
for PEGASUS
[+210374+274018-92B](#)



201230C
for PEGASUS
[+210371+274018-92B](#)



201230C
for PEGASUS
[+210503+274018-92B](#)



277118
for PEGASUS
[EX3216-02/223K](#)



277119
for PEGASUS
[EX3216-03/223K](#)

PRESSER FOOT for OVERLOCK & INTERLOCK SEWING MACHINES



277122
for PEGASUS
[EX3216-04/435K](#)



257321A56
for PEGASUS
[W561-02BB](#)



257331A56
for PEGASUS
[W561-05BB](#)

HIRING FEET



P952
S952



P950
S950



P5
P5R
2.0mm



P5W
2.8mm

COMPENSATING FEET

CR SERIES



CR 1/32E(21R)	1/32" (0.8mm)	CR 1/32	1/32" (0.8mm)
CR 1/16E(211)	1/16" (1.6mm)	CR 1/16	1/16" (1.6mm)
CR 1/8E(212)	1/8" (3.2mm)	CR 1/32NS	1/32" (0.8mm)
CR 3/16E(213)	3/16" (4.8mm)	CR 1/16NS	1/16" (1.6mm)
CR 1/4E(214)	1/4" (6.4mm)	CR 1/32NK	1/32" (0.8mm)
CR 5/16E(215R)	5/16" (8.0mm)	CR 1/16NK	1/16" (1.6mm)
CR 3/8E(216R)	3/8" (9.5mm)		
CR 1/2E(218R)	1/2" (12.7mm)		

CL SERIES



CL 1/32E(22L)	1/32" (0.8mm)	CL 1/32	1/32" (0.8mm)
CL 1/16E(221)	1/16" (1.6mm)	CL 1/16	1/16" (1.6mm)
CR 1/32N(210)	1/32" (0.8mm)	CL 1/32NS	1/32" (0.8mm)
CR 1/16N(211N)	1/16" (1.6mm)	CL 1/16NS	1/16" (1.6mm)
CL 1/32N(220)	1/32" (0.8mm)		
CL 1/16N(221N)	1/16" (1.6mm)		

NR/NL SERIES



NR-31S	1/32" (0.8mm)
NL-31S	1/16" (1.6mm)

211 SERIES



211-13	1/16" x 3/16"
211-14	1/16" x 1/4"
211-15	1/16" x 5/16"
211-16	1/16" x 3/8"
211-18	1/16" x 1/2"

HINGED RAISING FEET

P81 L/R(12463HL/R) SERIES



P810(12463HR 1/32)	P810L(12463HL 1/32)	1/32" (0.8mm)
P811(12463HR 1/16)	P811L(12463HL 1/16)	1/16" (1.6mm)
P8115(12463HR 3/32)	P8115L(12463HL 3/32)	3/32" (2.4mm)
P812(12463HR 1/8)	P812L(12463HL 1/8)	1/8" (3.2mm)
P8125(12463HR 5/32)	P8125L(12463HL 5/32)	5/32" (4.0mm)
P813(12463HR 3/16)	P813L(12463HL 3/16)	3/16" (4.8mm)
P814(12463HR 1/4)	P814L(12463HL 1/4)	1/4" (6.4mm)
P815(12463HR 5/16)	P815L(12463HL 5/16)	5/16" (8.0mm)
P816(12463HR 3/8)	P816L(12463HL 3/8)	3/8" (9.5mm)
P818(12463HR 1/2)	P818L(12463HL 1/2)	1/2" (12.7mm)

PIPPING FEET

P69 L/D(36069L/DG) SERIES



P69L 1/8(36069L 1/8)	1/8" (3.2mm)
P69L 1/4(36069L 1/4)	1/4" (6.4mm)
P69L 3/8(36069L 3/8)	3/8" (9.5mm)
P69L 1/2(36069L 1/2)	1/2" (12.7mm)
P69D 1/8(36069DG 1/8)	1/8" (3.2mm)
P69D 3/16(36069DG 3/16)	3/16" (4.8mm)
P69D 1/4(36069DG 1/4)	1/4" (6.4mm)

HEMMING & FOLDING FEET



S543	6.0 mm
S544	19.0 mm

SPECIAL PIPPING FEET

P301C/P31C(31358L/12435R) SERIES



P301C	1/8(31358L 1/8)	1/8" (3.2mm)
P301C	3/16(31358L 3/16)	3/16" (4.8mm)
P301C	1/4(31358L 1/4)	1/4" (6.4mm)
P31C	1/8(12435R 1/8)	1/8" (3.2mm)
P31C	3/16(12435R 3/16)	3/16" (4.8mm)
P31C	1/4(12435R 1/4)	1/4" (6.4mm)

HINGED STANDARD FEET WITH GUIDE

SP18/SP18L SERIES



SP18	1/32	SP18L	1/32	1/32" (0.8mm)
SP18	1/16	SP18L	1/16	1/16" (1.6mm)
SP18	1/8	SP18L	1/8	1/8" (3.2mm)
SP18	3/16	SP18L	3/16	3/16" (4.8mm)
SP18	1/4	SP18L	1/4	1/4" (6.4mm)
SP18	5/16	SP18L	5/16	5/16" (8.0mm)

QUILTER & GUIDE FEET



S524



R2E



SPK3

SPECIAL TUBE FEET



A225E
S534
55mm

CORDING FEET

P3 SERIES



- P36N(12435HN)
- P311N(12435N)
- P31(12435W)
- P301N(31358N)
- P301(31358W)
- P36LN(31358HN)
- P36L(31358HW)
- P36LW(31358HXW)

ZIPPER FEET



P363
40322SH



P363V
165010H



S518N



S518NS



S518L



P361
121950H



P360
121947H

STANDARD FEET



P58N
142058N



P351
54247



P193
19336



P946
121946



P127
127233



160342



S510



SM20 1/32



150789-001

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922) 49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
 Иваново (4932)77-34-06
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Россия (495)268-04-70

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Саратов (8342)22-96-24
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сыктывкар (8212)25-95-17
 Сургут (3462)77-98-35
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Казахстан (772)734-952-31

Тольяти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Улан-Удэ (3012)59-97-51
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

<https://goldeneagle.nt-rt.ru> || geo@nt-rt.ru